



Oben[®]

Skysill Series Carbon Fiber Tripods



You're on steady ground[®]

Thank You for choosing Oben.

These sturdy, multifeatured Skysill carbon-fiber tripods feature twist locks that let you quickly and effortlessly adjust your tripod's height up to nearly 6 feet while providing several options for low-angle shooting. Skysill models with a 90° lateral option offer a center column that can be set at a 90° angle and rotated 360° around the tripod. This is ideal for shots that require camera positions that aren't available with traditional tripods, like close-up macro or document photography. Each leg can be positioned independently at three locking angles, and a built-in bubble level helps keep the tripod aligned with the horizon—both essential features when working on uneven terrain.


Skysill kits include Oben's BE Series dual-action ballhead that features two locks for independent adjustment of the ball and panoramic base. An Arca-type quick-release plate allows for quickly mounting and swapping cameras, so you'll have the right camera on your tripod and never miss an opportunity to capture the perfect shot.

Note: Images are for illustrative purposes only. Actual products may vary.

Key Features	4-7
Operation	8-17
Interchangeable Feet	8
Leg Length Adjustment	8
Leg Angle Adjustment	9
Center-Column Adjustment	10
Low-Angle Setup	11-13
Reversing the Center Column	11,13
Using the Short Center Column	12
Lateral Setup	14-15
Counterweight	15
The Mounting Plate	16-17
Reversing the Screw	16
Mounting a Head	17
Attaching Accessories	17
Warnings	18
Optional Accessories	18
Specifications	19

KEY FEATURES


Model CFT-6394



- Ⓐ Reversible 3/8-16 and 1/4-20 head mounting screw
- Ⓑ Mounting plate
- Ⓒ Set screws
- Ⓓ Reversible center column
- Ⓔ Center column locking collar
- Ⓕ Bubble level
- Ⓖ Strap loop
- Ⓗ 3/8-16 accessory socket
- Ⓘ Leg angle adjustment lock
- Ⓢ Rubberized nonslip leg warmers
- Ⓚ Retractable and removable weight hook
- Ⓛ Twist locks
- Ⓜ Removable rubber feet
- Ⓝ Short center column
- Ⓞ Spiked feet
- Ⓟ Hex keys (×2)

KEY FEATURES

Model CFT-6194L



- Ⓐ Reversible 3/8-16 and 1/4-20 head mounting screw
- Ⓑ Mounting plate
- Ⓒ Set screws
- Ⓓ Reversible center column
- Ⓔ Lateral rotating ring
- Ⓕ 90° notch
- Ⓖ Center column locking knob
- Ⓗ Bubble level
- Ⓘ Center column lateral opening
- Ⓢ Strap loop
- Ⓚ Leg angle adjustment lock
- Ⓛ 3/8-16 accessory socket
- Ⓜ Rubberized nonslip leg warmers
- Ⓝ Locking button
- Ⓞ Twist locks
- Ⓟ Removable rubber feet
- Ⓠ Spiked feet
- Ⓡ Hex keys (×2)


Interchangeable Feet

The rubber feet that come attached to the tripod are good for hard surfaces like hardwood floors, pavement, or carpet that you don't want to damage with spikes.

Spiked feet are good for soft surfaces where some extra security is needed, like grass or dirt.

To exchange the rubber feet for the spiked feet:


1. Unscrew the rubber feet from the tripod legs.
2. Screw in the spiked feet.
3. Insert the large hex key through the hole of each foot to tighten it until it's secure.



Leg Length Adjustment

Use the twist locks to adjust the length of the tripod's legs.

To adjust the height of a leg, loosen the lock by turning it a half-turn clockwise, and position the leg at the desired height. Turn the twist lock counterclockwise to tighten until secure.



For rapid deployment to maximum height, simultaneously twist


all three locks, and let the leg sections fall into place.

Note: When setting up the tripod on an uneven surface, refer to the integrated bubble level to ensure that the mounting plate is straight and aligned with the horizon.

Leg Angle Adjustment

For stable support when shooting on uneven terrain, each tripod leg can be individually set at a preset angle.

To increase the leg angle, do the following:



1. Slide the adjustment lock in the direction of the arrow. You may need to move the leg so it moves slightly in toward the center in order to move the adjustment lock.
2. Set the angle of the leg to one of the three preset positions.
3. Release the lock to secure the leg at the desired angle.

To decrease the angle, move the leg in toward the center until the lock clicks on the next preset.


Fully extending the center column and the legs will place the camera at the highest position possible with this tripod.

Center-Column Adjustment

CFT-6394

To adjust the height of the center column, turn the locking collar counterclockwise to disengage the lock, and move the center column to the desired height.


Turn the twist lock clockwise to tighten the lock. Make sure that the lock is adequately tightened to support the weight of the load on the mounting plate.



CFT-6194L

To adjust the height of the center column, turn the center-column lock counterclockwise to disengage the lock, and move the center column to the desired height.

Turn the center-column locking knob clockwise to tighten it. Make sure the lock is adequately tightened to support the weight of the load on the mounting plate.



Note: Extending the center column will make the tripod less stable. Extend the legs first, and extend the center column if needed.

Low-Angle Setup



CFT-6394

There are two ways to adjust the tripod for low-angle shots.

REVERSING THE CENTER COLUMN

Reversing the center column allows you to place your camera almost at ground level.

1. Remove your camera from the tripod.
2. Remove the weight hook from the bottom of the center column by unscrewing it and pulling it out of the center column.
3. Loosen the center-column's locking collar, pull the center column out of the tripod.
4. Reverse the center column, and align with the guide tabs inside the tripod's ring.
5. Reinsert the center column by sliding it up from underneath the tripod and through the center ring. Tighten the locking collar until secure.
6. Replace the weight hook by screwing it into the end of the center column.






Low-Angle Setup (continued)

USING THE SHORT CENTER COLUMN

The short center column allows an extremely wide leg angle for low-angle shots from close to ground level or on uneven terrain.



1. Follow steps 1 through 3 in *Reversing the Center Column* above.
2. Align the guide tabs inside the tripod's ring with the groove on the short center column, with the guide tabs inside the tripod's ring and slide the center column into the tripod. Tighten the twist lock until secure.
3. Remove the mounting plate from the center column. Loosen the top set screw on the mounting plate by turning it counterclockwise with the small hex key. Then unscrew the mounting plate by turning it counterclockwise.
4. Screw the mounting plate onto the short center column, and tighten the top set screw until it's secure.
5. For extra security, screw the weight hook into the bottom of the short center column after it's installed into the tripod.



CFT-6194L**REVERSING THE CENTER COLUMN**

Important! For the Skysill tripod to operate smoothly, several components must be aligned.


This figure shows the correct orientation with the lines at the top of the tripod leg and the lateral rotating ring, and the center column's locking pin properly aligned.



1. Loosen the locking knob, and raise the center column to its maximum height.

2. While holding the center column with one hand, press the locking button at the bottom of the center column, and raise the center column until it stops.

3. Press the locking button again, and pull the center column out of the tripod.



4. Press and hold on the center-column locking button while you insert the center column from underneath the tripod.

5. Tighten the center-column lock until secure.



Lateral Setup


CFT-6194L

The center column can be set to a 90° angle and rotated a full 360°.


Important! When you mount a camera to the tripod in this configuration, make sure to extend the camera over one of the tripod legs. To improve stability, counterweight your tripod as necessary.

1. Loosen the center-column lock, and raise the center column to its maximum height.
2. Press the locking button at the bottom of the center column, and raise the center column until it stops. Then lower the center column to the 90° angle.
3. Once the center column is sitting at the 90° angle, slide the center column through the lateral opening until reaching the desired lateral position.
4. Swivel the center column around the tripod as desired.
5. Once the center column is in position, tighten the center-column lock until secure.





Note: The center column lock is a spring-loaded ratchet handle. When the center column is blocking the full rotation of the lock, turn the lock as far as it will go. Pull it out, reposition it, and let the spring pull it back to reengage it. Continue to tighten or loosen the lock.




TO RETURN THE CENTER COLUMN TO THE UPRIGHT POSITION:

1. Extend the center column out until it stops.
2. Tilt it up until it's vertical, and slide it down into the center ring.
3. Tighten the center-column lock until secure.

Counterweight

CFT-6394

To improve the tripod's stability in windy conditions or when using a telephoto lens, use the built-in spring-loaded hook at the bottom of the center column.



Pull down the hook to hang a counterweight, such as the Impact saddle sandbag or a loaded equipment bag.



The Mounting Plate

REVERSING THE SCREW

The tripod includes a mounting screw with a 1/4-20 thread on one end and a 3/8-16 thread on the other. This allows you to mount a tripod head with either sized socket.

To switch between the two sizes of mounting screw, follow these steps:


1. Use the smallest hex key to loosen the top set screw on the mounting plate by turning it counterclockwise.
2. Unscrew the mounting plate from the tripod by turning it counterclockwise.
3. Remove the screw, and return the opposite end back into the plate.
4. Screw the mounting plate back into the tripod by turning it clockwise. Make sure the screw is completely seated inside the hole. When switching to the 1/4-20 screw, only the 1/4-20 screw should be visible above the mounting plate.
5. Tighten the set screw until it's secure.



Important! Tighten the set screw until it's snug. Don't overtighten.

MOUNTING A HEAD

Align the bottom of the head with the tripod's mounting screw, then twist clockwise until fully secured. Do not overtighten, as this may damage the head or the mounting screw.




The mounting plate is equipped with a set screw, which clamps against the base of the head to prevent unintentional loosening and to ensure the head is securely locked onto the tripod.

Turn the set screw counter-clockwise to secure the mounting plate to the head until it's snug. Don't overtighten.

Attaching Accessories

The Skysill tripod is outfitted with a 3/8-16 accessory socket that can be used to add accessories such as an LED light, microphone, monitor, or flash to your tripod setup.



The 3/8-16 accessory socket is compatible with most articulating and accessory arms. It has an anti-twist design that works best with articulating arms with a similar anti-twist design, such as the Axler Recodo Series of Articulating Arms.



Warnings:

- *Do not exceed the tripod's maximum load capacity.*
- *Ensure that all appropriate locks are engaged when necessary.*
- *The tripod should be used only in temperatures between -22°F and 140°F (-30°C and 60°C).*
- *Do not operate in salt water. Dry the tripod off if it becomes wet.*
- *Remove the camera from the tripod during transport.*
- *Keep out of reach of children.*
- *Always support the camera on top of the center column with one hand while adjusting the center column's height.*

OPTIONAL ACCESSORIES

Oben Tripod Strap with Quick-Release Loop and Spring Lock

- *TS-10*
- *TS-100*

Oben Deluxe Tripod Strap with Swivel Clip

- *TS-110*

Oben Tripod Strap with Two Quick-Release Loops

- *TS-20*
- *TS-200*

Oben Tripod Hammock

- *STB-10*

Visit our website at **ObenSupports.com**
for more Oben products.

	CFT-6394	CFT-6194L
Maximum Height with Center Column Extended	71.7 in. (1.8 m)	67 in. (1.7 m)
Maximum Height w/o Center Column Extended	61.7 in. (1.6 m)	53 in. (1.3 m)
Minimum Height	6.5 in. (16.5 cm)	3.6 in. (9.1 cm)
Folded Length	24.3 in. (61.7 cm)	21.5 in. (54.6 cm)
Maximum Load	39 lb. (17.7 kg)	19 lb. (8.6 kg)
Weight	4.9 lb. (2.2 kg)	4.2 lb. (1.9 kg)
Leg Sections	4	4
Center Column	Standard	90° Lateral

Note: The values in this specification chart reflect only the values of the tripod legs and not the tripod kits.



www.obensupports.com

Oben is a registered trademark of the Gradus Group.
© 2020 Gradus Group LLC. All Rights Reserved.